

# Frame Mark4-7

## User manual



---

## Content

1. <b>Components</b> .....	3
1.1. Screws .....	3
1.2. Nuts .....	3
1.3 Body kit.....	4
2. <b>Assembly</b> .....	5
2.1. Frame assembly.....	5
3. <b>Contacts:</b> .....	10

# 1. Components

## 1.1. Screws



Fig. 1. M2 x 5 mm 2 pcs



Fig. 2. M3 x 12 mm 4 pcs



Fig. 3. M3 x 25 mm 4 pcs



Fig. 4. M3 x 14 mm 4 pcs



Fig. 5. M3 x 10 mm 4 pcs



Fig. 6. M3 x 8 mm 12 pcs



Fig. 7. M3 x 18 mm 4 pcs



Fig. 8. M3 x 25 mm 4 pcs

## 1.2. Nuts



Fig. 9. M3 4 pcs



Fig. 10. M3 4 pcs

### 1.3 Body kit




Fig. 11. Plate A. 1 pcs



Fig. 12. Plate B. 1 pcs



Fig. 13. Plates C. 2 pcs



Fig. 14. Fastener strap. 2 pcs



Fig. 15. Rubber pad. 1 pcs



Fig. 16. Arms. 4 pcs






Fig. 17. Antenna holder. 2 pcs



Fig. 18. Camera holder. 2 pcs

## 2. Assembly

### 2.1. Frame assembly

	<p>Frame components.</p>
	<p>Take 4 pcs of arms (Fig.16), plate B 1pcs (Fig.12), plates C 2pcs (Fig.13), M3 x 14 mm 4 pcs (Fig.4) and M3 x 12 mm 4 pcs (Fig.2).</p>
	<p>Place 4 pcs of arms onto Plate B. Ensure that the holes in the arms are perfectly aligned with the holes in the plate.</p> <p><b>Note:</b> Position the plate so that the pre-installed press-fit nuts are on the upper side.</p>



Invert the assembly as shown.  
Place two Plates C onto the underside of the frame, ensuring that the mounting holes in the arms are perfectly aligned with the holes in the plates.




Insert four M3 x 14mm screws (Fig.4) into the central holes, as shown.



Invert the assembly as shown.  
Secure all components together using M3 x 12 mm 4 pcs (Fig.2), screwing them into the pre-installed press-fit nuts as shown.




The view from the opposite side should appear as shown below.  
Take M3 x 18 mm 4 pcs (Fig.7).



Thread M3 x 22 mm 4 pcs onto the protruding screws and tighten them securely.




Take M3 x 29 mm 4 pcs (Fig.8) and M3 x 8 mm 4 pcs (Fig.6).



Install them at the rear end and front end of the frame as indicated.



Take antenna holder 1 pcs (Fig.17) and prepared assembly.



Slide the 2 pcs of antenna holders onto the 2 pcs of M3 x 25 mm screws located at the rear of the frame as shown.



Take antenna holder 1 pcs (Fig.17) and prepared assembly.



Insert it into prepared assembly as shown.



Take camera holder 2 pcs (Fig.18), plate A 1 pcs (Fig.11) and prepared assembly.



Mount the two camera holders onto Plate A at the front of the frame. Ensure that the holders are seated correctly in the designated mounting holes.



Connect the two prepared assemblies together as shown.



Take plate M3 x 8 mm 8 pcs (Fig.6) and prepared assembly. Screw them to secure plate A to the prepared assembly. Fully tighten all screws on the frame assembly.



Take rubber pad 1 pcs (Fig.15) and prepared assembly.



Use the adhesive tape on the back of the pad to secure them firmly to the frame plate.

Press down firmly for a few seconds to ensure a strong bond.



Final Result.

### 3. Contacts:

WhatsApp: +420 777 054 888

Email: [support@pilotix.eu](mailto:support@pilotix.eu)

Telegram: [https://t.me/PilotixSupport\\_bot](https://t.me/PilotixSupport_bot)